

## Instructions For:

# Simpo Sign



## Product Specifications

Visible Graphic : 22" W x 28" H

Total Graphic Print Size: 22" W x 28" H

Graphic may be printed on adhesive-backed vinyl or painted directly onto the surface.

Foot Print Dimensions: 24" W x 24" D

## Product Parts

1 - Fold-Up Simpo Sign

2 - Handle

3 - Graphic Surface

4 - Support Rod

5 - Feet



### Step 1

Take all parts out of the box.

### Step 2

Lay the Signicade (1) flat on a clean surface.

If Graphic is Adhesive-Backed Vinyl:

Clean the Graphic Surface (3) with rubbing alcohol and affix the Graphic. Slowly smooth the Graphic to the Surface (3) as you remove the protective film backing. Repeat on back side.



If Graphic will be Painted: Clean and Prepare the Graphic Surface (3) with Gesso or other appropriate painting surface preparations. Let surface preparations dry, and then paint the Graphic on the surface. Repeat on back side.

### Step 3

Use the Handle (2) to carry the sign into place, and allow the front and back to separate. Pull the front and back of the Fold-Up Simpo Sign (1) apart until the unit stands on its own.



### Step 4

Locate the Support Rod (4) clamped to the back side of the Feet (5) and pull to remove it. Place each hooked end of the Support Rod (4) in the holes in the bottom center of each half of the Fold-Up Sign (1).



### Step 5

Use the Handle (2) to move the assembled sign into place.

